Mineure HPC-SBD

A short overview of High Performance Computing

Stéphane Vialle

Stephane.Vialle@centralesupelec.fr
http://www.metz.supelec.fr/~vialle

What is « HPC » ?

High performance hardware

Numerical algorithms

Serial optimization – tilling
Vectorization
Multithreading
Message passing

Parallel programming

Intensive computing & large scale applications

High Performance Computing → TeraFlops, PetaFlops, ExaFlops

« HPDA »

Big Data → TeraBytes, PetaBytes, ExaBytes

2

High Performance Hardware

Inside ….

… high performance hardware

3

High Performance Hardware

From core to SuperComputer



Computing cores

4

High Performance Hardware

From core to SuperComputer



Computing cores
with vector units



Unités AVX

5

High Performance Hardware

From core to SuperComputer



Computing cores
with vector units

Multi-core
processor

6

High Performance Hardware

From core to SuperComputer



Computing cores with vector units

Multi-core processor

Multi-core PC/node

7

High Performance Hardware

From core to SuperComputer



Computing cores with vector units

Multi-core processor

Multi-core PC/node

Multi-core PC cluster

8

High Performance Hardware

From core to SuperComputer



Computing cores with vector units

Multi-core processor

Multi-core PC/node

Multi-core PC cluster

Super-Computer

9

High Performance Hardware

From core to SuperComputer



Computing cores with vector units

Multi-core processor

Multi-core PC/node

Multi-core PC cluster

Super-Computer

+ hardware accelerators

10

High Performance Hardware

Top500 site: HPC roadmap

High Performance Hardware

Top500 site: HPC roadmap



→ Regular improvement allows to plan the future

12

High Performance Hardware

HPC in the cloud ?

Microsoft Azure

« AZUR BigCompute »

- High performance nodes
- High performance interconnect (Infiniband)

→ **Customers can allocate a part of a HPC cluster**

aws

- Allows to allocate a huge number of nodes for a short time
- No high performance interconnection network

→ **Comfortable for Big Data scaling benchmarks**

Some HPC or Large Scale PC-clusters exist in some Clouds

But no *SuperComputer* available in a cloud

13

Architecture issues

Why multi-core processors ?



Shared or distributed memory ?

14

Architecture issues

Re-interpreted Moore's law

Processor performance increase due to parallelism since 2004:



CPU performance increase is due to (different) parallel mechanisms since several years…

… and they require explicit parallel programming

W. Kirshenmann EDF & EPI AlGorille, d'après une première étude menée par SpiralGen

15

Architecture issues

Re-interpreted Moore's law

Impossible to dissipate so much electrical power in the silicium



Auteur : Jack Dongara

Architecture issues

Re-interpreted Moore's law



It became impossible to dissipate the energy consummed by the semiconductor when the frequency increased !

17

Architecture issues

Re-interpreted Moore's law

To bound frequency and to increase the nb of cores is energy efficient

Power Cost of Frequency

- Power ∝ Voltage² x Frequency (V²F)
- Frequency ∝ Voltage
- Power ∝ Frequency³

	Cores	V	Freq	Perf	Power	PE (Bops/watt)
Superscalar	1	1	1	1	1	1
"New" Superscalar	1X	1.5X	1.5X	1.5X	3.3X	0.45X
Multicore	2X	0.75X	0.75X	1.5X	0.8X	1.88X

(Bigger # is better)

$2 \times 0.75^3 = 0.8$

50% more performance with 20% less power

Preferable to use multiple slower devices, than one superfast device

Auteur : Jack Dongara

Architecture issues

Re-interpreted Moore's law

Initial (electronic) Moore's law:
each 18 months → x2 number of transistors per µm²

Previous computer science interpretation:
each 18 months → x2 processor speed

New computer science interpretation:
each 24 months → x2 number of cores



Leads to a massive parallelism challenge:
to split many codes in 100, 1000, ….. 10^6 threads … 10^7 threads!!

Architecture issues

3 classic parallel architectures

Shared-memory machines (*Symetric MultiProcessor*):



One principle:
- several implementations,
- different costs,
- different speeds.

Overview *of Recent Supercomputers*
Aad J. van der Steen
Jack J. Dongarra

Architecture issues

3 classic parallel architectures

Distributed-memory machines (*clusters*):



Hypercubes



Fat trees



Gigabit Ethernet

Cluster basic principles, but cost and speed depend on the interconnection network !

Highly scalable architecture

3 classic parallel architectures

***Distributed Shared Memory* machines (DSM):**



cache coherence Non Uniform Memory Architecture (**cc**NUMA)

Extends the cache mechanism

Up to 1024 nodes
Support global multithreading

Overview *of Recent Supercomputers*
Aad J. van der Steen
Jack J. Dongarra

Hardware implementation: fast & expensive…
Software implementation: slow & cheap !

3 classic parallel architectures







- Simple and efficient up to … 16 processors. Limited solution
- Unlimited scalability. But efficiency and price depend on the interconnect.
- Comfortable and efficient solution. Efficient hardware implementation up to 1000 processors.

2016 : almost all supercomputers have a cluster-like architecture

Evolution of parallel architectures

% of computing power in Top500



% of 500 systems in Top500



Pure SIMD
Single processor
SMP
ShM vector machine
MPP (cluster with custom interconnect)
Cluster

2016 : almost all supercomputers have a cluster-like architecture

BUT … →

Architecture issues

Modern parallel architecture

One PC cluster



One NUMA node

Cluster architecture:



Architecture issues

Modern parallel architecture

Cluster of NUMA nodes



Time to access a data in the RAM of the processor

< Time to access a data in a RAM attached to another processor
(several access times exist inside one NUMA node)

< Time to send/recv a data to/from another node

→ **« Hierarchical architecture »:**

→ {data – thread} location become critic

Architecture issues

Multi-paradigms programming

Cluster of multi-processor NUMA nodes with hardware vector accelerators

Hierarchical and hybrid architectures :

→ multi-paradigms programming
(or new *high level paradigm*…)

AVX vectorization:
#pragma simd

+ CPU multithreading:
#pragma omp parallel for

+ Message passing:
MPI_Send(…, Me-1,…);
MPI_Recv(..., Me+1,…);

+ GPU vectorization
myKernel<<<grid,bloc>>>(…)

+ *checkpointing*

27

Architecture issues

Distributed application deployment

Distributed Software Architecture



- Achieving **efficient mapping**
  How to map software and hardware ressource ?
- Achieving **fault tolerance**
  Which strategy and mechanisms ?
- Achieving **scalability**
  Are my algorithm, mapping and fault tolerance strategy adapted to larger systems ?

Distributed Hardware Architecture

Fault Tolerance in HPC

Can we run a very large and long parallel computation, and succeed ?

Can a one-million core parallel program run during one week ?



29

Fault tolerance

Mean Time Between Failures

MTBF definition:



$$\text{Mean time between failures} = \text{MTBF} = \frac{\sum(\text{start of downtime} - \text{start of uptime})}{\text{number of failures}}$$

30

Fault tolerance

Mean Time Between Failures

Experiments:

The Cray-1 required extensive maintenance. Initially, **MTBF was on the order of 50 hours.** MTBF is Mean Time Between Failures, and in this case, it was the average time the Cray-1 worked without any failures. Two hours of everyday was typically set aside for preventive maintenance…. (Cray-1 : 1976)

System Resilience at Extreme Scale
White Paper
Prepared for Dr. William Harrod, Defense Advanced Research Project Agency (DARPA)

Today, 20% or more of the computing capacity in a large high-performance computing system is wasted due to failures and recoveries. **Typical MTBF is from 8 hours to 15 days.** As systems increase in size to field petascale computing capability and beyond, the MTBF will go lower and more capacity will be lost.

Addressing Failures in Exascale Computing
report produced by a workshop on "Addressing Failures in Exascale Computing"
2012-2013

31

Fault tolerance

Why do we need fault tolerance ?

Processor frequency is limited and number of cores increases
→ **we use more and more cores**

We do not attempt to speedup our applications
→ **we process larger problems in constant time !** (Gustafson's law)

We use more and more cores during the same time
→ **probability of failure increases!**

We (really) need for fault tolerance
or large parallel applications will never end!

32

Fault tolerance

Fault tolerance strategies

High Performance Computing: big computations (batch mode)
→ *Checkpoint/restart* is the usual solution
→ **Complexify src code,** time consumming, disk consumming !

High Throuhgput Computing: flow of small and time constrained tasks
→ Small and independent tasks
→ A task is re-run (entirely) when failure happens

Fault tolerance in HPC remains a « hot topic »

Big Data:
→ Data storage redundancy
→ Computation on (frequently) incomplete data sets …

Different approach !

33

Energy Consumption

1 PetaFlops: 2.3 MW !
→ 1 ExaFlops : 2.3 GW !! 350 MW ! ….. 20 MW ?

?

Perhaps we will be able to build the machines,
but not to pay for the energy consumption !!

34

Energy consumption

How much electrical power for an Exaflops ?

1.0 Exaflops should be reached close to 2020:

- 2.0 GWatts with the flop/watt ratio of 2008 Top500 1st machine
- 1.2 GWatts with the flop/watt ratio of 2011 Top500 1st machine
- 350 MWatts if the flop/watt ratio increases regularly
- 20 MWatts if we succeed to improve the architecture ? …
  … « the maximum energy cost we can support ! » (2010)
- 2 MWatts …
  … « the maximum cost for a large set of customers » (2014)

35

Energy consumption

From Petaflops to Exaflops

1.00 Exaflops : ~~2018-2020~~
2020-2022

25 Tb/s (IO)
20/35 MWatt max….

×1000 perf
× 100 cores/node
× 10 nodes
× 50 IO
× 10 energy
(only × 10)

122 Petaflops : juin 2018

Summit – IBM, Oak Ridge - USA
IBM POWER9 22C 3.07GHz
NVIDIA Volta GV100
2 282 544 « cores »
8.8 MWatt

1.03 Petaflops : June 2008

RoadRunner (IBM)
Opteron + PowerXCell
122440 « cores »
500 Gb/s (IO)
2.35 Mwatt !!!!!!

- How to program these machines ?
- How to train large programmer teams ?

36

Energy consumption

Sunway TaihuLight - China: N°1 2016 - 2017

93.0 Pflops

- 41 000 processors Sunway SW26010 260C 1.45GHz
  → 10 649 600 « cores »
- Sunway interconnect:
  5-level integrated hierarchy
  (Infiniband like ?)

15.4 MWatt





Energy consumption

Summit - USA: N°1 June 2018

122.3 Pflops (×1.31)

- 9 216 processors IBM POWER9 **22C 3.07GHz**
- 27 648 **GPU Volta** GV100
  → 2 282 544 « cores »
- interconnect: Dual-rail Mellanox EDR **Infiniband**

8.8 MWatt (×0.57) **Flops/Watt : ×2.3**



Energy consumption

Summit - USA: N°1 November 2018

143.5 Pflops (×1.54)

- 9 216 processors IBM POWER9 **22C 3.07GHz**
- 27 648 **GPU Volta** GV100
  → 2 282 544 « cores »
- interconnect: Dual-rail Mellanox EDR **Infiniband**

9.8 MWatt (×0.64) **Flops/Watt : ×2.4**



Energy consumption

What is the sustainable architecture ?

Différentes stratégies s'affrontent dans le Top500 :

- La performance à tous prix avec de gros CPUs très gourmands
  Cray XT6 : 1.7 Pflops, 6.9 Mwatts
  K-Computer : 10.5 Pflops, 12.6 MWatts
- Beaucoup de processeurs moyennement puissants et peu gourmands
  IBM Blue Gene (gamme terminée)
- Utilisation d'accélérateurs matériels : GPU, ~~Xeon phi~~, …
  → machines hybrides : CPU + accélérateurs
  → difficiles à programmer et pas adaptées à tous les problèmes

Quel est le(s) bon(s) choix pour atteindre l'Exaflops ?

Quel est le choix pertinent pour de « plus petits » clusters ?

40

Cooling

Cooling is close to 30% of the energy consumption



Optimization is mandatory!

41

Cooling

Cooling is strategic !

Des processeurs moins gourmands en énergie :

- on essaie de limiter la consommation de chaque processeur
- les processeurs passent en mode économique s'ils sont inutilisés
- on améliore le rendement flops/watt

Mais une densité de processeurs en hausse :

- une tendance à la limitation de la taille totale des machines (en m² au sol)

→ **Besoin de refroidissement efficace et bon marché (!)**

Souvent estimé à 30% de la dépense énergétique!

Cooling

Optimized air flow

Optimisation des flux d'air : en entrée et en sortie des armoires

- Architecture Blue Gene : haute densité de processeurs
- Objectif d'encombrement minimal (au sol) et de consommation énergétique minimale
- **Formes triangulaires ajoutées pour optimiser le flux d'air**

IBM Blue Gene



43

Cooling

Cold doors (air+water cooling)

On refroidit par eau une « porte/grille » dans laquelle circule un flux d'air, qui vient de refroidir la machine



Exploded View of Active Rear Door Rack Cooling System

Le refroidissement se concentre sur l'armoire.

Cooling

Direct liquid cooling

On amène de l'eau froide directement sur le point chaud, mais l'eau reste isolée de l'électronique.

- Expérimental en 2009
- Adopté depuis (IBM, BULL, …)

Carte expérimentale IBM en 2009 (projet Blue Water)



Lame de calcul IBM en 2012 Commercialisée



Cooling

Liquid and immersive cooling

Refroidissement par immersion des cartes dans un liquide électriquement neutre, et refroidi.



Refroidissement liquide par immersion testé par SGI & Novec en 2014



Cray 2 (1985)

- 4 processeurs
- 1.9 Gflops
- FLuorocarbon

Refroidissement liquide par immersion sur le CRAY-2 en 1985

46

Cooling

Extreme air cooling

Refroidissement avec de l'air à température ambiante :

- circulant à grande vitesse
- circulant à gros volume

→ Les CPUs fonctionnent proche de leur température max supportable (ex : 35°C sur une carte mère sans pb)

→ Il n'y a pas de refroidissement du flux d'air.

Une machine de Grid'5000 à Grenoble (la seule en *Extreme Cooling*)

Economique !

Mais arrêt de la machine quand l'air ambiant est trop chaud (l'été) !

47

Cooling

Extreme air cooling

Refroidissement avec de l'air à température ambiante :

- circulant à grande vitesse
- circulant à gros volume

→ Les CPUs fonctionnent proche de leur température max supportable (ex : 35°C sur une carte mère sans pb)

→ Il n'y a pas de refroidissement du flux d'air.

Installation Iliium à CentraleSupélec à Metz (*blockchain - 2018*)

Economique !

Mais arrêt de la machine quand l'air ambiant est trop chaud (l'été) !

48

CentraleSupélec

Interesting history of CRAY company



49

CentraleSupélec

A short overview of
High Performance Computing

Questions ?

50